



Tube Pro™ Inc. Waterpark Tube Inflation/Deflation Instructions

INFLATION:

Remove the PVC vinyl tube from the packaging and make sure to **SAVE** the PVC repair kit patches with small glue tube included in the plastic bag. When preparing to inflate the tube, lay the tube down with the graphics facing upward and spread out as flat as possible.

To inflate the main chamber of the tube, insert nozzle of air pump into the opening of the small push-in valve. Inflate the main chamber of the tube using a small air compressor, air mattress pump or blower until the tube takes shape and is fully inflated. **Do not over inflate** the main air chamber of the vinyl tube. To close the push in valve secure the rubber end cap into the valve opening and push into the tube. Refer to the Tube Pro™ photo at the bottom of page for a properly inflated tube.

DEFLATION/STORAGE:

To deflate the main air chamber of the tube, unplug the rubber end cap from the valve opening. Let air escape to deflate and fold and curl as necessary to remove excess air. Vinyl tubes should be stored without sharp creases in the PVC. Do not tightly vacuum the tube.

Note: Tube may naturally deflate due to seasonal air pressure changes. Additional air may be required before use.

PATCH REPAIRS:

Each waterpark tube includes two PVC patch pieces and 1 small glue tube for repairs. For best results, ensure tube repair area is clean and dry. Cut a smaller circular patch piece as needed for the repair area. Apply a thin layer of glue to the cut circular patch and around the tube area where air is escaping. After allowing a few minutes for the glue to 'tack', place the patch on the leaky area and apply pressure to smooth and adhere the patch to the tube. Secure the patch with a weight or small clamp. The glue provided is urethane based and creates a strong chemical bond as the solvent evaporates. For best results the glue will need to dry for a couple hours, allowing time for curing and maximum bond.



Read warning label on product prior to using.

International Safety Alert Warning Descriptions

	This is the safety alert symbol. It is used to alert you to potential personal injury hazards.
WARNING	WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
WARNING	
This product is not a lifesaving device. Do not leave children unattended while in use. Use only under competent supervision. Always sit upright when riding/floating. Do not jump or dive on product. Do not tow behind watercraft and other vehicles. Always wear a life jacket in deep water. Inspect item condition before each use. Do not use damaged product. Reluctance to follow guidelines may result in injury or product failure. Refer to instructions for proper inflation of product, description of safety warnings and recommended rider capacity.	
Tube Pro Inc., Made in China	



Have fun and be careful.

Tube Pro Inc.