

TUBE PRO™

Tube Pro Inc. Waterpark In-line Raft Inflation/Deflation Instructions

INFLATION:

Remove the PVC raft from the packaging. When preparing to inflate the raft, lay the raft bottom flat with the black bottom spread out as evenly as possible. Inflate the H3 inflation valve of the two PVC raft backrests first, before inflation on main raft air chamber.



Inflate the PVC raft backrest then main air chamber using an air compressor, towable tube pump, blower, or air mattress pump so it appears tight and feels firm to the touch. A properly inflated raft has no more than 2-3 pounds of air pressure. (Refer to Tube Pro Waterpark raft photo at bottom of page displaying a properly inflated in-line raft.) Inflate the backrests first then the main air chamber of the raft by unscrewing the H3 valve core as shown below, and inserting H3 raft inflator adaptor attached to your blower. If using an air compressor, retrofit a small piece of hosing to mount to your air compressor nozzle to ensure a sealed area around the valve.

DEFLATION/STORAGE:

To deflate PVC raft, remove the plastic screw-cap by hand. Use your thumb, a small blunt object, or air pump H3 raft nozzle to push in the valve spring center to release air. Fold and curl raft as necessary to remove excess air from the main raft air chamber and interior two backrests. Once the PVC raft is deflated, fasten the plastic screw cap(s) for storage.

Note: Raft may naturally deflate due to seasonal air pressure changes. Additional air may be required before use.

International Safety Alert Warning Descriptions

	<p>This is the safety alert symbol. It is used to alert you to potential personal injury hazards.</p>
 <p>WARNING</p>	<p>WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.</p>




This is not a lifesaving device.

Do not attempt to tow behind boats or other vehicles.

Have fun and be careful.

Tube Pro Inc.

AIR COMPRESSOR HOSE ADAPTOR



H3 RAFT HOSE ATTACHMENT & INFLATION VALVE

