



Steerable River Tube & Paddle Inflation/Deflation Instructions/Safety Warnings

INFLATION:

Remove the **TubeTracker™** PVC tube and paddle from the packaging. First, assemble two piece paddle shaft together, with oar-rings on the ends of the shaft. Then proceed to screw the paddle blades into both ends of the paddle shaft until securely tightened. When preparing to inflate the tube, lay the tube unit with the graphics facing up and spread out as evenly as possible. It is important to inflate the seat air chamber first via the small push-in valve. Inflate seat using a portable blower, or air mattress pump with proper attachment nozzle. If using an air compressor, attach the blow nozzle to airline. The inflatable seat utilizes a small one-way push-in safety valve. If having difficulty opening the one way safety valve for inflation, insert small plastic straw that comes in packet with repair patches to aid in air flow. Inflate the seat air chamber until firm, but do not over inflate.

To inflate the main air chamber of the tube, make sure the black plastic boston valve is securely tightened by turning the round textured base of the valve cap to the right. Next, loosen the square top of the boston valve cap by turning it to the left, while ensuring the round base stays securely tightened in place. Inflate the main chamber of the tube using a small air compressor, air mattress pump or blower until the tube takes shape and is fully inflated, or taught/firm to the touch. Our custom **TubeTracker™** vinyl tube takes shape quickly during inflation. Do not over inflate the main air chamber of the vinyl tube. To close the boston valve securely, tighten the valve by turning the square top cap to the right. Refer to the **TubeTracker™** photos at the bottom of page to view a properly inflated tube. A properly inflated **TubeTracker™** requires approximately 1.5-2.0 lbs of air pressure and will approximately match the 60"x40" inflated specification. Please refer to www.tubeproinc.com for more photos of properly inflated tubes.

DEFLATION/STORAGE:

To deflate the main air chamber of the tube, remove the boston valve cap from the recessed valve port. To loosen valve cap, turn the round textured base to the left. Next deflate seat air chamber and fold and curl as necessary to remove excess air. Once the vinyl PVC tube is deflated, reinstall the boston valve core and tighten cap securely at the base for storage. The **TubeTracker™** should be stored without sharp creases in the PVC. Do not tightly vacuum the tube.

Note: Tube may naturally deflate due to seasonal air pressure changes. Additional air may be required before use.

RE-INFLATION:

****When re-inflating vinyl tubes, ensure the main chamber boston valve is screwed tightly.****

PATCH REPAIRS:

Each waterpark tube includes two PVC patch pieces and 1 small glue tube for repairs. For best results, ensure tube repair area is clean and dry. Cut a smaller circular patch piece as needed for the repair area. Apply a thin layer of glue to the cut circular patch and around the tube area where air is escaping. After allowing a few minutes for the glue to 'tack', place the patch on the leaky area and apply pressure to smooth and adhere the patch to the tube. Secure the patch with a weight or small clamp. The glue provided is urethane based and creates a strong chemical bond as the solvent evaporates. For best results the glue will need to dry for a couple hours, allowing time for curing and maximum bond.



Read warning label on product prior to using.

International Safety Alert Warning Descriptions

	This is the safety alert symbol. It is used to alert you to potential personal injury hazards.
WARNING	WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
WARNING	
<p>This product is not a lifesaving, or personal floatation device. Do not leave children unattended while in use. Use only under competent supervision. Always sit upright when riding/floating. Do not jump or dive on product. Do not tow behind watercraft and other vehicles. Always wear a life jacket or approved PFD while using product. Inspect item condition before each use. Do not use damaged product. Reluctance to follow guidelines may result in injury or product failure. Refer to instructions for proper inflation of product, description of safety warnings and recommended rider capacity.</p> <p>INFLATABLE FLOOR - Inflate floor/seat first, via small push-in valve. MAIN CHAMBER – Inflate main chamber after floor/seat, via boston Valve.</p> <p style="text-align: center;">Tube Pro Inc., Made in China</p>	



Have fun and be careful.

Tube Pro Inc.